

DISCONNECT OPERATOR ARM FROM BOTTOM OF SASH, THEN DISCONNECT THE SUPPORT ARM FROM THE STUD ON THE FRAME JAMB. THIS WILL ALLOW THE SASH TO SLIDE DOWN IN THE TRACK UNTILL THE SLIDE SHOE BECOMES FREE.

